


Slatwall Brackets for 42"H Panels

Installation Instructions

002821D Rev C Page 1 of 1



Slatwall Brackets for 42"H Panels

WSW42AN - Answer
WSW42AV - Avenir
WSW42S9 - S9000

1 Insert brackets into panel at desired height, shift down to engage.

2 Install anti-dislodgement clips. Secure with screws provided.

Anti-dislodgement clip

3 Attach Slatwall.

a Slide top portion of Slatwall into mounted bracket.

b Drop bottom portion of Slatwall into bracket.

Note: For proper installation, Slatwall hooks should be upward.

4 Insert Slatwall Retention Clip into top of each bracket to prevent accidental dislodgment.

For a better day at work.™

details®

A STEELCASE COMPANY

P.O. Box 1967 / CD-5E / Grand Rapids, MI 49501-1967 / www.details-worktools.com

©2007 Office Details Inc. All rights reserved. Printed in U.S.A. 8/07