




Installation Instructions

0001791 Rev A

Galilei
Cable Rings
KCR



Push Cable Rings directly into Slatwall. Cable Rings can turn at 45° angles. Route wire(s) through rings in desired fashion.



For a better day at work.™

details®

A STEELCASE COMPANY

www.details-worktools.com
P.O. Box 1967 Grand Rapids, MI 49501-1967
All rights reserved. Printed in U.S.A. 1/05




Installation Instructions

0001791 Rev A

Galilei
Cable Rings
KCR



Push Cable Rings directly into Slatwall. Cable Rings can turn at 45° angles. Route wire(s) through rings in desired fashion.



For a better day at work.™

details®

A STEELCASE COMPANY

www.details-worktools.com
P.O. Box 1967 Grand Rapids, MI 49501-1967
All rights reserved. Printed in U.S.A. 1/05




Installation Instructions

0001791 Rev A

Galilei
Cable Rings
KCR



Push Cable Rings directly into Slatwall. Cable Rings can turn at 45° angles. Route wire(s) through rings in desired fashion.



For a better day at work.™

details®

A STEELCASE COMPANY

www.details-worktools.com
P.O. Box 1967 Grand Rapids, MI 49501-1967
All rights reserved. Printed in U.S.A. 1/05




Installation Instructions

0001791 Rev A

Galilei
Cable Rings
KCR



Push Cable Rings directly into Slatwall. Cable Rings can turn at 45° angles. Route wire(s) through rings in desired fashion.



For a better day at work.™

details®

A STEELCASE COMPANY

www.details-worktools.com
P.O. Box 1967 Grand Rapids, MI 49501-1967
All rights reserved. Printed in U.S.A. 1/05