


003644D Rev A

Installation Instructions


Interface Bracket

WSRB10

WSRB4



Use the Post & Beam Interface Bracket to attach
Organizational Worktools to your Post & Beam Fence.



For a better day at work.™

details®

A STEELCASE COMPANY

www.details-worktools.com

P.O. Box 1967 Grand Rapids, MI 49501-1967

All rights reserved. Printed in U.S.A. 10/04